

How To: Change your MUD Password

The default Password for your MUD can be easily changed

Note: The User/Login Name can't be changed

Default:

User Name = **pi**

Password = **myUSBdr1ve!** (case sensitive)

NOTE: ⚠ Security Warning - MyUsbDrive ⚠

No security is enabled by default. Any computer or user connected to your network will have full read and write access to any USB drive shared by MyUsbDrive

Strongly recommended:

To protect your device and data **Change the default Password immediately**

There are two ways to access and rename your MUD


- 1- Your MUD directly connected to a Monitor or TV via a HDMI cable
- 2- Remotely from a PC on your network using PuTTY or MobaXterm (SSH and telnet client)

1 - How to: Connected to a Monitor or TV:

At the 'Login' prompt enter - **pi**


At the 'Password' prompt enter - **myUSBdr1ve!** (case sensitive)

- once logged in; enter - **sudo raspi-config** and press 'Enter' (raspi-config will now appear)
- Select - '**System Options**' and press 'Enter'




1.1

Select - 'Password' and press 'Enter'



1.2


Select - 'OK' and press 'Enter'



1.3

Change the Password and press 'Enter'


Confirm the Password and press 'Enter'



```
tim@Apache: ~  
File Edit Tabs Help  
tim@Apache:~ $ sudo raspi-config  
New password:  
Retype new password: 
```


1.4

"Password changed successfully" select 'OK' and press 'Enter'



1.5

Right arrow twice and select '**Finish**' and press '**Enter**'



1.6

Reboot your MUD for changes to make effect

2 - How to: - Connected via PuTTY or MobaXterm:

The process once logged into your MUD via PuTTY or MobaXterm is as above

Next:

Open PuTTY or MobaXterm

Enter your MUD's IP address and click open

At the 'Login' prompt enter - **pi**

At the 'Password' prompt enter - **myUSBdr1ve!** (case sensitive)

once logged in; enter - sudo raspi-config and press '**Enter**' (raspi-config will now appear)

Continue as above