

How To: Use MUD's Web Interface

There is an interface that we do not normally tell people about because it is [Webmin](#) and can be quite complicated:

- Continue only if you feel happy to do so
- How to use can be found here – [Documentation](#)

Login method:

From your PC Browser

- Use the IP or Host name of your MUD and port 10000
 - Example – [HTTPS://192.168.0.10:10000](https://192.168.0.10:10000)
- User Name = pi
- Password = myUSBdr1ve! (default & case sensitive)
- Password = ??????? (as re-set by you)

